


For Technical Support visit us at www.sunsetter.com/ownerscorner or Call Toll Free 800-670-7071 • Fax 877-224-4944



Tube #4 End Cap Replacement Instructions

Tools Needed: Phillips Screwdriver

Parts Supplied: End Cap, Mounting Screws (qty 2)

<u>WARNING</u>: FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN PERSONAL INJURY! PLEASE READ THESE INSTRUCTIONS COMPLETELY BEFORE PERFORMING THIS PROCEDURE.

- 1. Remove the pole from the ground sleeve.
- 2. Remove the two end cap mounting screws near the bottom of the pole.
- 3. Remove the end cap using pliers to hold the rib in the center of the cap.
- 4. Align the slot in the end cap with the rib in the tube, and slide the new end cap into the tube.
- 5. Align the screw holes in the end cap with the screw holes in the flagpole and install the two mounting screws.
- 6. Test the flagpole for proper operation.